



CITROËN
CUSTOMER SERVICES
AFTER SALES TECHNICAL DEPARTMENT

TECHNICAL BULLETIN

XM

1

CONCERNING:
ALL COUNTRIES

CONCERNING:
CITROËN XM
V6-24 Valve Engine
Characteristics and Checks


No. 23

APPLYING TO:
ALL COUNTRIES

30th April, 1991

THIS DOCUMENT IS TO BE FILED IN: BULLETIN BINDER No. MAN 058930

CITROËN XM V6 .24



SKZ 6-CYLINDER ENGINE

SUMMARY:

GENERAL CHARACTERISTICS

Pages

2

ENGINE

- I - Characteristics
- II - Construction

3

4

INJECTION-IGNITION

- I - Fuel circuit
- II - Pneumatic circuit
- III - Air circuit
- IV - Electrical circuit
- V - Operating phases
- VI - Diagnosis
- VII - Adjustments
- VIII - Component Identification

8

10

11

14

18

22

27

28

GENERAL CHARACTERISTICS

| | |
|----------------------------|------------|
| Commercial name | XM V6.24 v |
| Factory symbol | Y 3-A L |
| Guarantee type | Y 3-A L |
| French fiscal rating | 16 CV |
| Number of seats | 5 |

● DIMENSIONS:

Dimensions unchanged. Refer to Technical Bulletin XM ① No. 1.

● WEIGHTS:

| | |
|--|---------|
| - Unladen weight | 1465 kg |
| - on front axle | 935 kg |
| - on rear axle | 530 kg |
| - Gross vehicle weight | 1920 kg |
| - on front axle | 1095 kg |
| - on rear axle | 835 kg |
| - Gross train weight | 3420 kg |
| - Max. trailer weight (without brakes) | 720 kg |
| - Max. trailer weight (with brakes) | 1500 kg |
| - Max. trailer nose weight | 110 kg |
| - Max. weight on roof rack | 80 kg |

● PERFORMANCE:

| | |
|---|------------|
| - 400 m standing start (driver only) | 15.8 s |
| - 1000 m standing start (driver only) | 28.6 s |
| - 0 - 62 m.p.h. (driver only) | 8 s |
| - Maximum speed | 146 m.p.h. |

● FUEL CONSUMPTION:

| | |
|---------------------|-------------|
| - At 56 m.p.h. | 34.4 m.p.g. |
| - At 75 m.p.h. | 27.7 m.p.g. |
| - Urban | 17.8 m.p.g. |

● GEARBOX:

| TYPE | REFERENCE | ENGINE | TYRES | LADEN ROLLING CIRCUMFERENCE |
|-------|-----------|--------|-------------------|-----------------------------|
| ME5 T | 2 GM 02 | SKZ | 205 / 60 R15 MXV2 | 1.920 m |


| GEAR | GEARBOX RATIO | FINAL DRIVE RATIO | OVERALL RATIO | SPEED mph per 1000 rpm |
|------|---------------|-------------------|---------------|------------------------|
| 1 | 12 x 38 | 15 x 61 | 0.0776 | 5.56 |
| 2 | 18 x 33 | | 0.1341 | 9.59 |
| 3 | 28 x 35 | | 0.1967 | 14.08 |
| 4 | 32 x 31 | | 0.2538 | 18.16 |
| 5 | 43 x 33 | | 0.3204 | 22.93 |
| Rev. | 13 x 41 | | 0.0779 | 5.57 |

Speedometer drive ratio: 25 x 20

ENGINE

I. CHARACTERISTICS

| | |
|------------------------------|---------------------|
| Vehicle factory symbol | Y 3-A L |
| Engine type | SKZ (ZPJ4) |
| Number of cylinders | 6 |
| Bore | 93 mm |
| Stroke | 73 mm |
| Cubic Capacity | 2975 cc |
| Compression ratio | 9.4: 1 |
| Max. power EEC | 147 kW at 6000 rpm |
| Max. torque EEC | 26 mdaN at 3600 rpm |
| Maximum rpm | 6400 |
| French fiscal rating | 16 CV |
| Recommended fuel | Unleaded petrol |
| Octane rating | 95 RON minimum |



II CONSTRUCTION

● Cylinder block:


Identical to ZPJ cylinder block.

● Moving parts:

Crankshaft identical to that of ZPJ engine, end float from 0.07 - 0.27 mm.
Bearings and seals identical to ZPJ engine.

● Con-rods - Pistons - Rings and Barrels:

Con-rods and barrels identical to ZPJ engine.



Piston rings: identical to ZPJ engine
 - chromed ring, 1.75 mm thickness
 - "eagle-beak" stepped ring, 1.75 mm thickness
 - scraper ring, 3.5 mm thickness

Barrels: identical to ZPJ engine
 Cast-iron, height 98.975 ± 0.025 mm
 Stand-proud: from 0.05 - 0.120 mm
 Adjustable by coated steel base seals in 3 sizes:

| COLOUR | SIZE |
|-------------------|----------------------|
| - Yellow - orange | 0.116 ± 0.018 mm |
| - Colourless | 0.136 ± 0.018 mm |
| - Blue | 0.166 ± 0.028 mm |


● Cylinder heads

In light alloy with 4 bearings.
 Single chain driven overhead camshaft in each cylinder head. The chain tensioner operates hydraulically and has a mechanical rearming device. 4 valves per cylinder operated by intermediate cam followers and hydraulic tappets housed in the rockers.

A support housing carries:

- two rocker shafts:
 - one shaft for individual inlet rockers (6 rockers per cylinder head),
 - one shaft for the one-piece exhaust rockers (3 per cylinder head),
- a balance shaft identical to ZPJ engine in the front cylinder head. The operating principle of the hydraulic tappet is described in Technical Bulletin XM ① No. 1, page 4.

ATTENTION: The centre cam followers are different:
 inlet: length 41.32 mm
 exhaust: length 40.12 mm



Y114

Cylinder head tightening:


Final head tightening is carried out on assembly.

After cylinder head removal:

TIGHTENING OF THE HEAD BOLTS is by the angular method (bolt head faces and threads lubricated), following a conventional circular sequence as shown:


- 1°) Tighten each bolt to **6 mdaN** in the order shown.
- 2°) Slacken each bolt in turn and retighten to **4 mdaN** plus a further angular tightening of **180°**.

DO NOT RETIGHTEN AT 1ST SERVICE



This tightening method is carried out with the engine cold and no subsequent tightening is required

Identification: (→)




Inlet valves (\varnothing 37 mm) with a green spring and exhaust valves (\varnothing 32 mm) with a red/black spring.
 Hexagonal headed cylinder head bolts, 178 mm in length.

The front and rear camshafts of the ZPJ4 engine are identical.

● Valve timing

Specific timing chains, 62 links (64 links on ZPJ).
Chain guide specific to this engine.



▶ Valve timing by reference marks on the chains.

● Lubrication:

7-tooth gear type oil pump driven by chain (identical to ZPJ engine).

| | |
|--|---|
| Capacity after draining | 6.5 litres |
| new engine | 7 litres |
| Difference between min. and max. levels .. | 2 litres |
| Recommended oil | TOTAL QUARTZ or TOTAL GOLD |
| Minimum oil pressure at 80°C | 5.5 bars at 5,500 rpm |
| Low oil pressure switch setting | 0.5 bar |
| Oil filter reference | PURFLUX LS 520 C, replace every 12000 miles |
| R.P. No. | 95 638 903 |


● Cooling system

Water pump driven by "polyvee" belt.

Specific coolant circuit: – heating of the 2 butterfly housings
– air conditioning as standard.

Draining, refilling and bleeding


| | |
|------------------|--|
| Draining | : – Remove the filler cap. – Unscrew the radiator drain plug – Drain the cylinder block by removing the two plugs on the right-hand rear and right-hand front of the cylinder block. |
| Refilling | : – Remove the filler cap. Note : There is no need to slacken the radiator bleed screw. – Top up to the level of the filler cap. |
| Bleeding | : – Refit the filler cap. – Start the engine and run it at 1500 - 3000 rpm to assist the bleeding. – Let it run until the cooling fans cut-in. – Switch off and wait for the engine to cool. – Top up coolant level to the MAX. mark. – Refit the filler cap. |



Y23-12

● Exhaust


A "6-into-1" manifold with "METEX" swivel joint for each cylinder head. As the front exhaust line is longer, a small priming catalyser, located under the engine, pre-treats the exhaust gas. This pre-treatment increases the exhaust gas temperature and the 2 main catalytic converters receive the gases from each bank at equal temperatures. Each cylinder bank gas has its own oxygen sensor and catalytic converter. A specific repair procedure allows certain components of the exhaust system to be replaced individually.



Y18-7

INJECTION - IGNITION

The **CITROEN XM V6 24v** is fitted with a **SIEMENS BENDIX AUTOMOTIVE ELECTRONICS (SBAE)** type **FENIX 4** injection and ignition system developed from the **V6 FENIX 3** system.



90-987

The **FENIX 4** system combines both injection and ignition systems in a single **computer**, the various engine sensors being common to both functions.

The fuel quantity, controlled by the "injector open" period, is delivered cylinder by cylinder every 2 engine revolutions: **sequential injection**. This "open period" or "injection period" is a function of an indirect calculation, made by the e.c.u., of the **mass of air** drawn into the cylinder. The e.c.u. receives from the sensors, information about **air pressure** and **temperature** in the inlet manifold and about engine speed. From its own cartographic map, the e.c.u. then calculates the **mass of air drawn** into the cylinder.

A **correction** to the injection time is made by the e.c.u. as a **function of both engine temperature and operating conditions**; information supplied by secondary sensors. These same sensors supply the information required for the **calculation of ignition advance**. A cylinder **reference sensor** enables the e.c.u. to **align** with the firing order: **1-6-3-5-2-4**.






Knock sensing is carried out cylinder by cylinder.


Mixture strength adjustment is controlled by the e.c.u. by means of two oxygen sensors (one per cylinder bank).


Two electro valves control the **ACAV** system (Variable Acoustic Characteristic Induction), varying the volume of the inlet manifold as a function of the conditions of engine use. This is known as "**controlled flow induction**".

The e.c.u. has an **autodiagnostic capability** which may be interrogated with equipment such as the **26A** or **OUT 10 4120T**. This can identify and report operational faults that may have occurred within the system.

| DESCRIPTION |
|-------------------------------|
| 1 E.c.u. |
| 2 Diagnostic socket |
| 3 Trip computer |
| 4 Diagnostic warning lamp |
| 5 Instrument panel |
| 6 Injectors |
| 7 Injector rail |
| 8 Pressure regulator |
| 9 Canister electro valve |
| 10 Canister electro valve |
| 11 Fuel filter |
| 12 Canister |
| 13 Fuel pump |
| 14 Fuel tank |
| 15 Rear catalytic converter |
| 16 Rear oxygen sensor |
| 17 Front catalytic converter |
| 18 Front oxygen sensor |
| 19 Battery |
| 20 Ignition switch |
| 21 Coded anti-theft pad |
| 22 Fuel pump relay |
| 23 Oxygen sensor relay |
| 24 Compressor relay |
| 25 Injection relay |
| 26 Air filter |
| 27 Idle regulator |
| 28 Air temperature sensor |
| 29 Butterfly potentiometer |
| 30 ACAV electro valve (short) |
| 31 Butterfly capsule (short) |
| 32 Butterfly capsule (long) |
| 33 ACAV electro valve (long) |
| 34 Absolute pressure sensor |
| 35 Compressor |
| 36 Coolant temperature sensor |
| 37 Flywheel sensor |
| 38 Ignition module |
| 39 Cylinder reference sensor |
| 40 Ignition coil |
| 41 Sparking plugs |
| 42 Front knock sensor |
| 43 Rear knock sensor |
| 44 Injectors. |

| | |
|---|----------------------|
|  | wiring harness |
|  | fuel circuit |
|  | fuel venting circuit |
|  | vacuum circuit |
|  | air circuit |






DESCRIPTION

- 1 ACVA electro valve (long)
- 2 ACVA capsule (long)
- 3 ACVA butterfly (long)
- 4 Pressure regulator
- 5 ACVA butterfly (short)
- 6 ACVA capsule (short)
- 7 ACVA electro valve (short)
- 8 Vacuum reservoir
- 9 Non-return valve.

— Long ACVA vacuum circuit
 - - - Vacuum reservoir circuit
 . . . Pressure regulator vacuum circuit
 - - - Short ACVA vacuum circuit.

I - PETROL CIRCUIT



► The following components are identical to those of the CITROËN XM V6:

- 1 Fuel tank
- 2 Fuel pick-up: tank unit and fuel pump
- 3 Fuel filter (replace every 48,000 miles)
- 4 Pressure regulator rated at 3 bars.

These components are described in Technical Bulletin XM ① No. 1.

► Specific components are:

- 5 Steel injector rail (in place of aluminium casting)
- 6 BOSCH injector rail (in place of BENDIX).



Note: As the injection is sequential, one injection of fuel every 2 engine revolutions, the injector connections are marked with the relevant cylinder number.

III - AIR CIRCUIT


Air filter identical to **CITROËN XM V6** replace every 24,000 miles.

Variable Acoustics Characteristics Induction (ACAV):

There are various ways of increasing engine performance: turbo charging, multi-valve...

The method used for the **CITROËN XM V6 24v** is by use of a multi-valve inlet and exhaust system completed by the **ACAV**.

The multi-valve inlet system provides good cylinder filling at high engine speeds. The problem of loss of torque at low engine speeds is corrected by induction with variable acoustic characteristics.



The ACAV uses the phenomenon of wave propagation in a given volume to optimise cylinder filling.

• *Operating principle:*

The manifold distributes the air to the cylinders and consists of 6 ducts. The injectors are mounted in these ducts and are located upstream of the inlet valves. The manifold is completed by the ACAV system.


The assembly consists of:

- two primary inlet air volumes,
- a link "L" (long) with two blanking butterflies,
- a link "C" (short) having one blanking butterfly,
- a vacuum reserve, the energy source for the capsules controlling the butterflies.


The two throttle butterflies, which open simultaneously, are controlled mechanically by the accelerator pedal.

The e.c.u. controls the operation of the two electro valves as a function of engine speed and throttle position, acting on information from the throttle potentiometer.


When an electro valve is supplied electrically, the vacuum reservoir is connected to the corresponding butterfly capsule which acts on the butterfly spindle.



Volume V1 is made up of 2 distinct halves, each supplied with air by a throttle butterfly connected to the air filter.



To smooth the transition between the two configurations during acceleration, an intermediate configuration exists. This creates a long, smaller diameter connecting link (length ≈ 400 mm) between the two halves.




The passage from MAXIMUM TORQUE configuration (2 halves are separate) to the MAXIMUM POWER configuration (2 halves linked as a single volume V1) is achieved by the opening of a short, large diameter tract (Ø 70 mm) between the two halves.

The switching between each configuration is carried out when under **FULL LOAD**:

- below 4,000 rpm (**A**) SEPARATION as far as the air filter,
- between 4,000 rpm and 5,000 rpm (**C**) LINKED (long tract opened by two butterflies of 50 mm diameter),
- above 5,000 rpm (**B**) FULLY INTERCONNECTED (short tract opened by a butterfly of 70 mm diameter).

NOTE: if the system is without fault, the long tract will remain open at all engine speeds above 4,000 rpm even for part-load conditions. This allows the inlet pressures of the two cylinder banks to balance and provides even distribution of the air from the idling regulator (when cold or at idle).

• OPERATING STAGES:




The FENIX 4 e.c.u. holds characteristic points of engine speed and corresponding engine loads in memory. Thus, it can control the electro valves to modify the inlet manifold volume according to the conditions of use:

• At low engine speeds: TORQUE obtained by SEPARATION.

Gas flow speed must be at the maximum to produce high torque:


- Butterflies (1) and (2) are closed,
- The two primary manifold volumes (3) and (4) are separate, supplying the respective cylinder bank.



• At intermediate engine speeds: TRANSITION "Torque/Power" obtained by LINKING.

The transition from the TORQUE phase to the POWER phase must be made smoothly:


- Butterflies (1) are open, butterfly (2) remains closed,
- The two primary manifold volumes (3) and (4) are linked by long link (L).



• At high engine speeds: POWER obtained by INTERCONNECTING.


For maximum power output, the cylinder must receive the maximum charge:

- Butterflies (1) and (2) are open,
- The two primary manifold volumes (3) and (4) are interconnected through short link C and long link L.



E.c.u.: SBAE FENIX 4

Located in the e.c.u. carrier on the right hand front wheel arch. Inputs and outputs are made through a 55-way connector.




Y14-12

The following components are specific to the CITROEN XM V6 24v:


E.c.u.
Oxygen sensors
Cylinder reference sensor
ACAV electro valves
Injectors.




BENDIX flywheel sensor (in bell housing).



GM absolute pressure sensor (on bulkhead).




BENDIX throttle potentiometer (on rear butterfly housing).




JAEGER air temperature sensor (grey connector) (in inlet manifold).




JAEGER coolant temperature sensor (green connector) (in coolant outlet housing).




EATON speed sensor (driven by speedometer cable).




Oxygen sensor for front bank.



Oxygen sensor for rear bank.



BOSCH knock sensors
One sensor per cylinder bank:
- green sensor - front bank
- blue sensor - rear bank.




JAEGER coded anti-theft key pad.



Cylinder reference sensor
(on rear head opposite the cam pulley).



Ignition circuit
The ignition module sends a primary voltage to the ignition coil which is transformed into a secondary voltage. This is sent to the appropriate cylinder by means of the distributor.




ACAV butterfly capsule **electro valves**.



ACAV butterfly **capsules**.

- **Other information** supplied by the e.c.u.:
As on the CITROEN XM V6, the e.c.u. controls:
 - the heating of the oxygen sensors
 - the tachometer information
 - the autodiagnostic warning lamp
 - the information required by the trip computer
 - the memorising of the incidents and their codes.

- **Purging of the canister** (if fitted).



Y 17-22

To optimise engine performance and conform to emission regulations, the e.c.u. controls the purging valve of the canister (1), recycling the fuel vapour from the tank. The purging is controlled as a function of engine operating conditions.

This valve is open at rest. To avoid an accumulation of fuel vapour in the inlet manifold, a second valve (closed at rest) (2) cuts off the canister purging circuit when the engine is not running.

ATTENTION: Make sure that the 2 valves are connected correctly.

Emission standard 15-05: 2-way white connector to 2-way black connector
(without canister) the other 2-way black connector remains unconnected.

Emission standard US 83: 3-way white connector to canister electro valve
a 2-way black connector to canister purge electro valve
the other 2-way black connector remains unconnected.

V - OPERATING PHASES

The FENIX 4 e.c.u. controls the injection and ignition system based on information from two principal sources:

- Pressure
- Engine speed.


Controlling the ignition

The e.c.u. sends the ignition module the necessary signal to trigger ignition. The cylinder reference sensor, mounted opposite the cam pulley enables the e.c.u. to time itself to No. 2 cylinder. The firing order remains: 1.6.3.5.2.4.

Ignition advance is calculated as a function of engine conditions: starting, idling control etc.

Knock sensing

The sensing principle is identical to that of the FENIX 3B system.



Y 21-18

The cylinder reference sensor enables the e.c.u. to determine which cylinder or cylinders are responsible for the knocking. On sensing knocking, the following adjustments are made:

- ignition advance: rapid and slow correction
- injection period: reduction of the quantity of fuel injected.

Injection operation

The 12 volt electro magnetic BOSCH injectors are controlled by the e.c.u. They are electrically supplied in six stages ie one stage per injector.

The injection mode is as follows:

- during starting phase: simultaneous injection every 1/3rd of a crankshaft revolution
- exiting starting phase: simultaneous injection every crankshaft revolution
- passing to sequential injection when the engine speed is above 300 rpm and the cylinder reference signal has been detected several times.

Controlling the variable acoustic characteristics induction (ACAV):


The ACAV systems consist of two primary volumes whose characteristics can be varied by opening and closing of butterflies. The butterflies are controlled by the e.c.u. using electro valves and pneumatic capsules:

- engine off or idling, the electro valves are not electrically supplied,
- engine speeds between idling and 4,000 rpm, the long link electro valve is energised if the engine is under load,
- engine speeds above 5,000 rpm, the short link electro valve is energised if the engine is under load.

Starting phase:

Entry into this phase is automatic and is triggered when the e.c.u. is supplied electrically, when the engine stalls and when the T.D.C. of No. 2 cylinder has been sensed.

- Ignition advance is a function of engine speed and temperature.
- Injection is simultaneous during the starting phase and occurs at each T.D.C. (every 1/3rd of a crankshaft revolution).



- The injection period $ti0$ is a function of coolant temperature, injection taking place at each T.D.C. (3 injections per revolution).

- Ignition advance is corrected as a function of engine temperature.

Exit from the starting phase can be triggered by:

- releasing the key from the starter position,
- exceeding a certain engine speed, determined by engine temperature,
- exceeding a pre-determined length of time.

During this phase, the idling actuator valve is wide open. When the engine fires, injection remains simultaneous for a minimum of 2 engine revolutions to confirm that the engine has started.

The injection then becomes sequential.

Controlling the idling speed:

The e.c.u. controls the idling once a pre-determined engine speed is reached and if the information from the throttle potentiometer corresponds to the closed throttle position.

To maintain a stable idling, the e.c.u. varies:

- the flow of air across the idling actuator valve.
- the fuel injected sequentially by each injector.

Idling regularity is achieved by instant changes to the ignition advance.

The e.c.u. uses information about engine temperature and load to determine the idling speed.

• Full engine load and transitional phases:

The e.c.u. controls the injection time and the ignition advance according to the driver's requirements, based on information of inlet manifold pressure and position or variation of the throttle potentiometer.

The e.c.u. can modify: the injection time (mixture strength) and the ignition advance (retard)

to avoid jerking or hesitation.

• Injection cut-off

The coded anti-theft key pad sends a multiplex message to the e.c.u. which must be recognized before injection can take place and therefore engine starting.

In order to conform to emission standards, injection is cut during deceleration if the following conditions occur simultaneously:

- coolant temperature above a pre-determined value
- engine speed above a threshold value
- closed throttle position information.

Injection is re-established when the engine speed falls below 1,500 rpm.

In case of overrevving the e.c.u. cuts off injection in 2 stages:

- at 6,400 rpm for one bank
- at 6,500 rpm for the second bank.

• Mixture control loop

Two oxygen sensors, one for each bank, inform the e.c.u. continuously of the oxygen content of the exhaust gases. The e.c.u. knows the conditions of each bank and modifies the injection period (and therefore mixture strength) of the bank concerned, accordingly.

This is known as a "closed" loop mixture control.

The mixture control loop may be "open" for one bank or for both banks of cylinders:

- if the oxygen sensors do not reach operating temperature,
- during the simultaneous injection phase (starting etc.),
- on deceleration,
- under full load and during injection cut-off for overrevving,
- if an injector is faulty,
- if a sensor is faulty.

• Coded anti-theft device:

The anti-theft device is fitted as standard to the CITROEN XM V6 24v, it sends a multiplex message to the e.c.u. which it must recognize before authorising injection to take place.

• E.c.u. self-correction

The e.c.u. can adapt itself to the engine it controls:

- the sealing of the engine during its life,
- different fuel qualities,
- condition of the injection components,
- production tolerance differences in engine.

It optimises the basic mixture settings to compensate for any variations.

The adjustments made by the self-correction function are reset after each interruption in the e.c.u. electrical supply:

- battery disconnected
- e.c.u. disconnected.

• Back-up or emergency mode:

The e.c.u. continuously checks the credibility of the various parameters of the system. In the case of a fault with a sensor, the e.c.u. will ignore the false signal and replace it with an acceptable figure. If the fault is considered to be serious, the autodiagnostic lamp in the instrument panel will light. If the fault disappears (intermittent problem) the warning lamp will be extinguished, and the e.c.u. will return to its normal operation, however the fault code will have been recorded by the e.c.u.

| CIRCUIT MALFUNCTION | VALUES MEASURED | BACK-UP VALUES ASSUMED | WARNING LAMP CONDITION |
|---------------------------------|---|--|------------------------|
| Air temperature | If the temperature measured is below - 40° C or above 120° C | Air temperature = Coolant temperature if it is below 20° C otherwise air temperature = 20° C. | OFF |
| Coolant temperature | If the temperature measured is below - 40° C or above 120° C | Coolant temperature = Air temperature when starting. Then progressively temperature = 90° C or temperature = 90° C if the fault occurs when the engine is running. | ON |
| Butterfly position | Values outside tolerances | Fixed value but no recognition of "pedal released" and "pedal fully depressed" positions. | OFF |
| Absolute pressure sensor | - If the manifold pressure is below 180 mbar, ignition on but engine not running. - If the pressure is not below recorded threshold when the engine is idling. | Value calculated in relation to throttle butterfly position. "Open loop" mixture control. | ON |
| Strategy for mixture regulation | Values measures are outside memorised tolerances | "Open loop" mixture control. | ON |
| Knock sensing | Comparison of the signals from the 2 sensors. | Retarding of the ignition advance on all points of the ignition map in the critical zone. | OFF |
| Cylinder reference sensor | If 6 T.D.C. positions are not sensed in 2 crankshaft revolutions | Retarding of the ignition advance on all points of the ignition map in the critical zone. | ON |
| Injectors | If the injector is open or short circuited. | "Open loop" mixture control on the relevant cylinder bank. | ON |

• Autodiagnosis - Actuating components

The e.c.u. continuously monitors the condition of the sensors and the actuating components, checking for:

- open circuit
- normal operation
- short circuit.

It memorises both intermittent and permanent faults occurring within the system. These fault codes may be retrieved using 4097 T, 4120 T or 26A units.

The actuating components can also be tested using the same equipment.

VI - DIAGNOSIS

FAULT FINDING PROCEDURE

The e.c.u. can memorise both intermittent and permanent faults. These faults may be retrieved in the form of codes by using the **4097T**, **4120T** or **26A** units.

BEWARE: Loss of the 12 volt supply to the e.c.u., for whatever reason, will erase any fault codes recorded, will reset the adjustments made by the self-correction function and will cause the coded anti-theft device to lock.

With this warning in mind, it is **ESSENTIAL** that the test sequence below is followed:

- Deactivate the anti-theft unit by selecting the neutral mode (code 0000).
- Carry out the preliminary checks.
- Read the fault codes and road test the vehicle to confirm fault where possible.
- Connect the electrical test unit OUT 30 **4109T**.
- Locate the fault.
- Repair the fault.
- Erase the memory of the e.c.u.

LIST OF CODES SPECIFIC TO THE FENIX 4 E.C.U. (fault codes and activation codes)

| | DESCRIPTION | CODE | | DESCRIPTION | CODE | |
|--|--------------------------------|------|--------------------------|-------------------------------|-----------------|----|
| | Start of test | 12 | | Front oxygen sensor | 51 | |
| | End of test | 11 | | Mixture adjustment front bank | 52 | |
| | | | | Battery voltage | 53 | |
| | | | | E.C.U. | 54 | |
| | Air temperature | 13 | FAULT CODES | Anti-theft key pad | 56 | |
| | Coolant temperature | 14 | | Rear knock sensor | 62 | |
| | Petrol pump relay | 15 | | Rear oxygen sensor | 63 | |
| | Butterfly potentiometer | 21 | | Mixture adjustment rear bank | 64 | |
| | Idling control valve | 22 | | Cylinder reference sensor | 65 | |
| | Idling adjustment stop | 23 | | No. 1 injector control | 71 | |
| | Long ACAV electro valve | 25 | | No. 2 injector control | 72 | |
| | Short ACAV electro valve | 26 | | No. 3 injector control | 73 | |
| | Speed sensor | 27 | | no. 4 injector control | 74 | |
| | Mixture control front bank | 31 | | No. 5 injector control | 75 | |
| | Mixture control rear bank | 32 | | No. 6 injector control | 76 | |
| | Inlet manifold pressure sensor | 33 | | | | |
| | Canister purge electro valve* | 34 | | OPERATIONAL CODES | Fuel pump relay | 91 |
| | Lambda probe heating control | 36 | | | Injectors | 92 |
| | Flywheel sensor | 41 | Idling control valve | | 93 | |
| | Anti-knock function | 43 | Canister purge valve* | | 94 | |
| | Front knock sensor | 44 | Long ACAV electro valve | | 96 | |
| | | | Short ACAV electro valve | | 97 | |


* it fitted (depending on emission standard)

PRELIMINARY CONTROLS

Before carrying out any work on the vehicle, the following points must be checked:








- 1** The system earth points for:
 - fuel pump, E.C.U., and battery.
- 2** Check the connections of the various system components:
 - pressure sensor, flywheel sensor, injectors and e.c.u.

ONLY THE GREEN LAMP OF THE CODED ANTI-THEFT KEY PAD SHOULD BE LIT












THE RED LAMP OF THE CODES ANTI-THEFT KEY PAD IS LIT

- The use of the anti-theft key pad is described in Technical Bulletin XM ① No. 1, pages 21 and 22.
- If the injection e.c.u. is locked (red and green lamps lit simultaneously) wait one minute (ignition on) before entering the correct code.
- If the red warning lamp remains lit, check the continuity of the installation.

| FAULT CODE | COMPONENT LOCATION | CHECKS | ECU CONNECTOR | 4108 T TERMINALS | COMPONENT TERMINALS | READINGS | EMERGENCY FUNCTION/LAMP | SERIOUS OR MINOR | INDUCED CODES |
|------------|--|---|---------------|--------------------------|--|---|---|------------------|---------------|
| 13 | Air temp sensor (907) on butterfly housing | Ohmmeter | Disconnected | 9-34 |  Grey | 4 K Ω at 10° C 2.5 K Ω at 20° C 690 Ω at 55° C If correct, check sensor supply voltage = 5V | Yes | m | |
| 14 | Water temp sensor (909) on coolant outlet housing | Ohmmeter | | |  Green | 4 K Ω at 10° C 2.5 K Ω at 20° C 690 Ω at 55° C 230 Ω at 90° C If correct, check sensor supply voltage = 5V | Yes  | S | 31 |
| 15 | Fuel pump relay (907) on e.c.u. housing | Actuation 4120 T Voltmeter Pressure Gauge | Connected | 54-8 | | With the aid of Code 91 the fuel pump should run and stop once per second for 15 seconds. Voltmeter should oscillate Check fuel pressure = 3 bars min. | No | m | 42 |
| 21 | Butterfly potentiometer (770) on butterfly housing | Voltmeter | Connected | 33 - 34 11 - 34 |  White | 5 volts \pm 0.5 volt throttle closed - 0.5 \pm 0.1 volt linear increase as throttle opened to 4.5 volts min | Yes | S | 31 |
| 22 | Idle regulator (432) on butterfly housing | Check for induction leaks Actuation 4120 T Voltmeter | Connected | 48 - 45 or 48 - 46 |  + and  and Grey | Squeeze the air intake pipe: The engine speed should drop below 500 rpm. If not, there is an air leak. With the aid of \rightarrow Code 93 The valve is opened fully once per second for 15 seconds. Voltmeter should oscillate. | No | m | 31 |
| 23 | Idle regulator stop (770) on butterfly potentiometer | Voltmeter | Connected | 11 - 34 |  White | Check for induction leaks. Check the throttle potentiometer adjustment - engine stopped, throttle closed: U = 0.5 \pm 0.1 volt | No | m | 31 |

LOGICAL FAULT DIAGNOSIS TABLES

| FAULT CODE | COMPONENT LOCATION | CHECK | ECU CONNECTOR | 4108 T TERMINALS | COMPONENT TERMINALS | FUNCTION | EMERGENCY OR BURNING LAMP | SERIOUS OR MINOR | INDUCED CODES |
|------------|---|--------------------------------|---------------------------------------|------------------|--|--|--|------------------|---------------|
| 25 | ACAV (440) electro-valve long circuit | Actuation 4120 T Voltmeter | Connected | 48-55 |  | With the aid of Code 96 the electrovalve is operated once during 15 seconds When supplied V = 12 volts | | | |
| 26 | ACAV (439) electro-valve short circuit | Actuation 4120 T Voltmeter | Connected | 48-52 | | With the aid of Code 97 the electrovalve is operated once during 15 seconds When supplied V = 12 volts | | | |
| 27 | Vehicle speed sensor (154) on bulkhead | Road test vehicle Voltmeter | Connected | 22-14 |  White on interface 9N3 & 9N8 | Ensure correct operation of average speed function on trip computer R = 300 Ω approx. Vehicle moving, approx. 1.5 V | No | m | 23 |
| 31 | Auto adjustment of mixture, Front bank on front Lambda sensor | Ohmmeter Voltmeter | Connected Connected engine running | 23-14 |  Red | - Checking the function of the ECU: allow 2 minutes for pre-heating of sensor Read voltage at terminals 23 & 14: 0 \rightarrow 1V \rightarrow 0 \rightarrow 1V - Read voltage at red connector if 0.8 V fixed - Check HT leads and sealing of exhaust upstream of sensor | No | m | 51-52 |
| 32 | Auto adjustment of mixture, Rear bank on rear lambda sensor | Voltmeter | Connected engine running | 4-14 |  Red | - As for 31 above except: Read voltage at terminals 4 & 14: 0 \rightarrow 1V \rightarrow 0 \rightarrow 1V | No | m | 51-52 |
| 33 | Absolute pressure sensor (903) on bulkhead | Voltmeter | Connected | 30-34 32-34 |  Green | V = 5 volts Using vacuum pump, vary the pressure: 400 Pa \rightarrow 2.5 V 600 Pa \rightarrow 1.25 V | Yes | S | |
| 34 | Canister electrovalve (430) if fitted on battery tray | Actuation 4120 T Voltmeter | Connected | 48-40 |  Black | With the aid of Code 94 the valve is operated twice per second for 15 seconds. Voltmeter will oscillate. | No | m | |
| 36 | Lambda sensor heating (900) on e.c.u. housing | Voltmeter | Connected | 53-39 |  Yellow | - From cold, at terms 13 + 1: V = 1 volt - On brown connector, V = approx. 12 volts The feed is triggered by relay 818 . - See sensor checking Code 31 . | No  | S | |
| 41 | Flywheel sensor (152) under the hydraulic pump | Ohmmeter | Disconnected | 16-35 16-14 |  Brown | - 330 Ω approx. Gap not adjustable: 0.5 to 1.5 mm Run out 0.4 mm max - Isolated from earth | No | m | |


| | | | | | | | | | | |
|----------------------------------|--|----------------------------------|--------------------------|-------------------------------------|----------------------------------|--|--|-----|---|------------------|
| 43 | Anti knock adjustment | | | | | | | Yes | S | 44-62 |
| 44 | Knock sensor (front) (150) green on front cylinder head | 15-36 15-14 | | 2 3 Green 4 | 15-36 15-14 | | 2 3 Green 4 | Yes | S | 43 |
| 51 | Lambda sensor (999) on catalytic converter | 23-39 | Connected | Voltmeter | 23-39 | | Red | No | S | 52 |
| 52 | Regulation of richness from front Lambda sensor | 23-39 | Connected engine running | Voltmeter | 23-39 | | Red | No | S | 51 |
| 53 | Supply voltage to sensors | 9 27 30 33 | Connected | Voltmeter | 9 27 30 33 | | Battery | No | m | 21 56 |
| 54 | ECU (144) | | | | | | ECU out of service | No | S | |
| 56 | Coded anti-theft keyboard (176) in console | | Connected | | | | The ECU has not got a fault but the injection function is locked: red light is on. Tap in the code, red light goes out, green light comes on. If this incident persists, disconnect battery for one minute before entering confidential code | Yes | m | |
| 62 | Knock sensor (Rear) (151) blue on rear cylinder head | 17-15 17-14 | | | 17-15 17-14 | | 2 3 Blue 1 | Yes | S | 43 |
| 63 | Lambda sensor (Rear) (900) on cat. converter | 4-39 | Connected engine running | Voltmeter | 4-39 | | Yellow | No | S | 64 |
| 64 | Regulation of richness from rear Lambda sensor (900) | 4-39 | Connected engine running | Voltmeter Ohmmeter | 4-39 | | Red | No | S | 63 |
| 65 | Cyl No. 2 reference sensor (160) | 31-12 31-39 | Connected engine running | Voltmeter Ohmmeter | 31-12 31-39 | | 2 3 Black 1 | No | S | |
| 71 72 73 74 75 76 | Injectors: → no. 1 → no. 2 → no. 3 → no. 4 → no. 5 → no. 6 | 43 20 42 44 38 21 | Disconnected | Actuation 4120 T Ohmmeter | 43 20 42 44 38 21 | | Black | No | S | If short circuit |
| | | | | | | | At idle V = 3 volts air gap = 1 mm ± 0.5 Resistance = R = 400 Ω Isolated from earth With the aid of Code 92 Disconnect fuel pump Create successive impulses at each injector → operation audible Injector resistance 16 Ω | No | | |

FENIX 4 ADJUSTMENTS

Idling: not adjustable

- The idling speed is determined by the e.c.u. with the aid of an idling electro valve.
- Idling speed: ≈ 750 rpm

DO NOT ALTER THE BUTTERFLY STOP SCREW SETTINGS



• **Synchronising the throttle butterflies:**

Remove the siamese ducting between the butterfly housing and the air filter housing.

- Slacken screw (1) and operate throttle lever (2) to open the butterfly (3).
- Tighten screw (1) until butterflies (3) and (4) are opened simultaneously. From this position, tighten screw (1) by one further turn.

• **Adjustment of the throttle quadrant roller:**

In the "closed throttle" position, roller G should turn freely but with no clearance for a movement of 3 mm of the quadrant (5) measured with a rod.

• **Adjusting the ACAV butterflies:** *In principle, there is no need to adjust the eccentrics E; the procedure described is for information only.*

Disconnect the two sections comprising the ACAV after removing the fixings.

Use an elastic band to hold lever L in the butterfly closed position; operate the lever two or three times.

Slacken the locknut and adjust the eccentric to obtain clearance J between the butterfly and the wall of the ACAV.

Long circuit butterflies J = 2.6 mm approx.

Short circuit butterfly J = 0.1 mm.

Retighten the lock nut and reassemble as necessary.

• **Checking the depression:**

– Vacuum reservoir at (5) between 400 and 800 mbar, engine off, the depression should not leak rapidly.

– Road tests in 3rd gear:

• below 4,000 rpm at (6): → no load, d = 0

→ full load, d > 650 mbar.

• above 5,000 rpm at (7):

→ no load, d = 0.

→ full load, d > 650 mbar.

• **Adjusting the butterfly potentiometer:**

Using the screws V:

▶ throttle closed: read 0.5 ± 0.1 volt at

terminals 11 and 34 of the e.c.u.


▶ throttle fully open: read 4.5 volts at these terminals.

• **Anti-pollution and ignition:** not adjustable.

• Sparking plugs **EYQUEM RFC 58 LS 3:** Flat seat plugs with sealing washer.

Electrode gap: 1 ± 0.1 mm

Tightening torque: 1.5 mdaN.



REPLACEMENT PARTS

| DESCRIPTION | MANUFACTURE | REFERENCE OR MARKING | RP NUMBER |
|-------------------------------|-------------|----------------------|---------------|
| E.C.U. | BENDIX | 5 101 880 101 | 96 039 263 |
| Butterfly potentiometer | BENDIX | 33 19380 - White | 96 033 193 |
| Flywheel sensor | ELECTRIFIL | C144 3030 - Brown | 96 037 097 |
| Pressure sensor | G.M. | 876 - Green | 96 052 503 |
| Coolant temperature sensor | JAEGER | 33 634 401 - Green | 95 640 493 |
| Air temperature sensor | JAEGER | 33 707 201 - Grey | 95 640 497 |
| Front knock sensor | BOSCH | Green | 96 037 065 |
| Rear knock sensor | BOSCH | Blue | 96 037 068 |
| Idling control valve | BOSCH | Grey | 74 01 317 957 |
| Injecteur | BOSCH | | 96 050 712 |
| ACAV electro valve | EATON | | 96 039 283 |
| ACAV capsule | HELLA | | 96 093 751 |
| Fuel pump | BOSCH | EKP 10 | 95 653 038 |
| Tank unit | JAEGER | | 95 653 039 |
| Coolant temperature interface | BITRON | SCT 100 | 95 658 682 |
| Anti-theft key pad | JAEGER | | 96 003 421 |
| Air filter element | | | 94 01 444 108 |
| Fuel pressure regulator | BOSCH | 0 280 160 232 | 74 01 271 132 |
| Coil | BOSCH | 0 221 122 411 | 96 048 064 |
| Ignition module | BOSCH | 0 227 100 124 | 96 048 070 |
| HT Distributor | BOSCH | 0 237 500 030 | 96 045 524 |
| HT lead set | BOUGICORD | | 96 061 817 |
| Distributor cap | BOSCH | | 96 054 877 |
| Rotor arm | BOSCH | | 77 00 267 693 |
| Sparking plugs | EYQUEM | RFC 58 LS 3 | 96 073 353 |
| Speed sensor | EATON | White | 96 008 161 |
| Speed interface | BITRON | IND. VE | 96 008 165 |
| Cylinder reference sensor | | | 96 067 317 |
| Oil filter | PURFLUX | LS 520 C | 95 638 903 |
| Fuel filter | PURFLUX | EP 90C | 91 535 807 |
| New engine | CITROËN | | 97 90 021 700 |
| Clutch friction disc | VALEO | 235 F32 BX 202 | 96 074 350 |
| Clutch pressure plate | VALEO | 235 CP 6050 | 96 088 393 |
| Clutch release bearing | VALEO | | 96 092 637 |
| Gearbox | CITROEN | ME5T | 95 649 233 |